


BTeV Pixel Detector Overview

David Christian Fermilab



BTeV Detector





BTeV, ATLAS, & CMS

The BTeV pixel detector is very similar to the ATLAS (& CMS) detectors in some respects, and very different in others.

Sensors

- Early decision to use 50μx400μ pixels (same as ATLAS), so that we could use ATLAS sensors for R&D
- ➤ Very similar radiation tolerance requirement (near the beamline).
 - Baseline is "moderated p-spray" n-in-n sensors using the (patented) ATLAS design.
 - ATLAS & CMS results prove radiation tolerance.

Bump Bonding

> Same pitch as ATLAS pixels.

Readout Electronics

- ➤ 396ns (or 132ns) between crossings vs. 25ns @LHC means timewalk is much less of a concern.
 - No need to trim each pixel discriminator threshold.
- ➤ Very high speed readout required to allow use of pixel data in lowest level trigger.

Operation in Vacuum


➤ Need to avoid liquid/vacuum joints makes cooling different.



Sensors

- Individual pixels are identical to ATLAS sensors.
- Number of rows & columns and overall size customized for BTeV.





By TESLA

Each wafer contains:


- 1 "4-chip" module
- 3 "6-chip" modules
- 3 "5-chip" modules
- 2 "8-chip" modules
- These are the modules used in the baseline design; number on wafer chosen to reflect usage.
- 5 "1-chip" sensors




Bump Bonding

- Same pitch as ATLAS pixels.
- Modules are smaller.

VTT solder bumps




AIT indium bumps





Pixel Readout Chip – FPIX2

- Development of readout chip is essentially complete.
 - > 0.25μ CMOS design has been verified radiation tolerant.
 - No degradation of analog performance after 87 Mrad.
 - Single event cross sections measured to be manageably small.
 - ➤ High speed readout implemented.
 - Data kept in pixels until it is transmitted off chip – no buffer memory.
 - Occupancy varies >x10 from point closest to the beam to edges furthest away.
 - Flexible serial data output interface allows the use of 1,2,4, or 6 (140 Mpbs) point-to-point LVDS (on copper)output links.






Operation in Tevatron Vacuum

- Driven by desire to have sensors as close to the beams as possible.
- Vacuum is maintained by a system of cryogenic pumps.
- Detector is built in two pieces (vertical split).
 - Moved away from beamline during beam injection, acceleration, etc.
 - Moved close to the beamline once beams are stable at high energy.
 - ➤ Horizontal magnetic field means that (to first order) tracks do not cross from left to right.
- Each half of the detector is supported by a carbon fiber composite "half cylinder."
- Heat is carried away from the pixels by *conduction* in solid substrate (Thermal Pyrolytic Graphite) to liquid nitrogen heat sinks above and below the pixel stations.
- Pixels are separated from the beams only by a thin "RF shield."
 - > Insures that microwave resonances are not excited in the vacuum box.




Cartoon of Pixel Module






Prototype Pixel Modules



Hybrids recently received from VTT (TESLA p-spray sensors bonded to FPIX2 chips with solder bumps).




Prototype High Density Interconnect (HDI).


Six FPIX2 chips glued & wire bonded to HDI (no sensor yet).



Module Layout on Half Planes











Pixel Half-Station (2 Half Planes)





Pixel Interconnect Flexible Cables (PIFC)

 Flex cables connect to Feed Through Board & then directly to the Data Combiner Board on standard data cables.





Pixel Detector Assembly

